


## MeterMatch-VR connection to PC Board-Mounted Gauge



\* Note: Alternatively, the fuel sender wire can be cut under the dash, and each cut end connected to MeterMatch terminals directly. This removes the need for isolation at the back of the gauge for this terminal.